W miljbee / PS3BluMote forked from Ben-Barron/PS3BluMote

## Works also with Smart Control PS3 URC 7965 / URC 7962

Edit New issue

#1

① Open

Heckie75 opened this issue an hour ago  $\cdot$  0 comments



Heckie75 commented an hour ago • edited ▼

Thanks for your effort!

The following is just for documentation my experiences. Everything works fine.

Your tool also works with OneForAll Smart Control PS3 URC 7965 / 7962.

https://www.oneforall.de/universal-fernbedienungen/urc-7965-smart-control-ps3/support

Vendor is: 0x1234 Product is: 0x4321

Here is the configuration:

```
<PS3BluMote version="2.0">
       <settings>
                <vendorid>0x1234/vendorid>
               cproductid>0x4321/productid>
               <smsinput>false</smsinput>
               <hibernation>false</hibernation>
               <repeatinterval>500</repeatinterval>
       </settings>
       <mappings>
                <button name="Eject" repeat="false">A</button>
                <button name="Audio" repeat="false"></button>
               <button name="Angle" repeat="false"></button>
               <button name="Subtitle" repeat="false"></button>
               <button name="Clear" repeat="false"></button>
               <button name="Time" repeat="false"></button>
               <button name="NUM_1" repeat="false">KEY_1</button>
               <button name="NUM_2" repeat="false">KEY_2</button>
               <button name="NUM_3" repeat="false">KEY_3</button>
               <button name="NUM_4" repeat="false">KEY_4</button>
               <button name="NUM_5" repeat="false">KEY_5</button>
               <button name="NUM_6" repeat="false">KEY_6</button>
               <button name="NUM_7" repeat="false">KEY_7</button>
               <button name="NUM_8" repeat="false">KEY_8</button>
                <button name="NUM_9" repeat="false">KEY_9</button>
               <button name="NUM_0" repeat="false">KEY_0</button>
               <button name="Blue" repeat="false"></button>
               <button name="Red" repeat="false"></button>
               <button name="Green" repeat="false"></button>
                <button name="Yellow" repeat="false"></button>
               <button name="Display" repeat="false">Tab</button>
               <button name="Top Menu" repeat="false"></button>
               <button name="PopUp_Menu" repeat="false">C</button>
               <button name="Return" repeat="false">Esc</button>
                <button name="Triangle" repeat="false"></button>
               <button name="Circle" repeat="false"></button>
               <button name="Square" repeat="false"></button>
               <button name="Cross" repeat="false"></button>
               <button name="Arrow_Up" repeat="false">Arrow_Up</button>
                <button name="Arrow_Down" repeat="false">Arrow_Down</button>
               <button name="Arrow Left" repeat="false">Arrow Left</button>
               <button name="Arrow_Right" repeat="false">Arrow_Right/button>
                <button name="Enter" repeat="false">Enter
               <button name="L1" repeat="false"></button>
               <button name="L2" repeat="false"></button>
               <button name="L3" repeat="false"></button>
               <button name="R1" repeat="false"></button>
                <button name="R2" repeat="true"></button>
               <button name="R3" repeat="false"></button>
               <button name="Playstation" repeat="false"></button>
               <button name="Select" repeat="false"></button>
                <button name="Start" repeat="false"></button>
                <button name="Play" repeat="false">Media_Play_Pause</button>
               <button name="Stop" repeat="false">Media_Stop</button>
               <button name="Pause" repeat="false">Media_Play_Pause</button>
               <button name="Scan_Back" repeat="false">Ctrl,Arrow_Left</button>
```

Assignees
No one assigned

Labels
None yet

Projects
None yet

Milestone
No milestone

Notifications

1 participant

Pairing the Bluetooth device in Windows 10 (at least since creators update) is a little bit tricky since the default way asks for a pin which is mandatory.

These instructions are required:

- 1. Right click the Bluetooth icon in the bottom-right corner of the screen, and select Add to Personal Area Network
- 2. On the top-left corner of the screen, click Add a new Bluetooth device.
- 3. Hold the pairing button of the IR receiver
  - 4, Wait until "BD Remote control" appears, select it and click Next.
- 4. Leave the PIN text box blank, and click Next.
- 5. Wait until device has been set up

Device code for remote control is 0772 which must be assigned to DVD. The newer code 2555 does not work here.

Heckie75 changed the title Works also with Smart Control PS3 URC 7965 / URC 7962 an hour ago